

# KBLED41 USB BLE Dongle\_1228

- Quick guide

- Part No: 829530

## Package Contents

KBLED41 USB BLE Dongle  
Quick guide  
Connect Barcode

## System Requirements

OS: Windows 7/8/10

## Specifications

Bluetooth Standards: Bluetooth Low Energy 4.1

Radio Frequency: 2.4 GHz - 2.4835 GHz

Physical Dimensions: 22mm x 15mm x 5.35mm (0.87" x 0.59" x 0.21")

Weight: 2.0g (0.07oz)

Antenna: Internal Chip Antenna

Input Power: 5V (USB bus-powered)

Power Consumption: 5V, 30mA max

Interface: USB 2.0 (HID)

Transfer Rate: Up to 1.0Mbps

Range: 30 meters (98 ft)

OS support: Windows 7/8/10




KOAMTAC

## KBLED41 USB BLE Dongle



## Quick Guide

1. Insert KBLED41 USB BLE Dongle into your computer.
2. Window will automatically install "HID Keyboard device" in the Device Manager of Control Panel as below picture.



3. Scan Connect Barcode to connect KDC to KBLED41 USB BLE Dongle.
4. KBLED41 USB BLE Dongle automatically connect to KDC.

5. Please attach a Connect Barcode to Windows PC case closed to KBLED41 USB BLE Dongle.

**KOAMTAC, Inc.**  
116 Village Blvd., Suite 305  
Princeton, NJ 08540, USA  
Phone: 609-256-4700  
FAX: 609-228-4373  
[www.koamtac.com](http://www.koamtac.com)